



1991-1996 Toyota Camry Headlight Replacement

Locating and replacing the headlight light bulbs for a Toyota Camry (1991-1996)

Written By: Matt Bowman



INTRODUCTION

When a headlight burns out, driving at night is more difficult and dangerous. Driving with only one headlight could get you fined.

Fortunately, replacing the bulb is easy.

Step 1 — Headlight



- To lift the hood of the car, pull the latch with the “hood up” icon up towards you. This latch can be found below the steering wheel and sits directly above where your left foot rests.
- After lifting the hood of the car, click the latch (located just above the Toyota logo visible on the front bumper) holding the hood down upward. Lift the hood upward.

Step 2



- Locate light plug (right side headlight plug shown). This can be found underneath the hood and is positioned directly behind the headlight.

Step 3



- Once you've found the light plug (left side shown), twist the light out of its locked position by rotating it counter clockwise (as seen in the video).
- Pull the bulb socket toward you to full remove it.

Step 4



- On the backside of the bulb socket, click the release lever down (as seen in the video). This will allow you to remove and replace the bulb
- Pull the old bulb end (which rests just above the previously mentioned release level) up to remove it
- Push new bulb end down until it clicks into position

To reassemble your device, follow these instructions in reverse order.